



LOK

REMOVABLE SCREEN PANEL INSTALLATION

Recommended tools



Hardware enclosed



POLYESTER



ACRYLIC

NOTE: all screws provided must be installed for proper installation and compliance with product warranty.



Lok tables are factory ready to receive privacy screens. Polyester and frosted acrylic screens can be ordered to coordinate with the table length or depth. removable brackets securely attach screens to underside of table top. Brackets are enclosed in the screen panel carton located in a hardware bag with **HARDWARE ENCLOSED** sticker.

polyester and acrylic privacy screen:

- Attach the leg of angle brackets without slot to the back of the polyester or acrylic screen into holes in panel with machine bolts provided into panel face trim covers.
- Position the screen panel with attached bracket to underside of table top and align slot with insert in backer. Install threaded knob.
- Privacy screens can be secured with #8 x 5/8" screw into underside of top



SCREEN SLID IN

"OUT" position provides opening to route cables from table top to undersurface



SCREEN SLID OUT