






Recommended Tools



Casegood Assembly



Package Contents



Hardware Used



#10 x 5/8" Pan Head Wood Screws



#12 x 5/8" Pan Head Wood Screws


Locking
Pin



Linking Hook & Latch


Step 1

Attach Legs to Cabinet:




Flip cabinet over on a
flat smooth surface

WARNING: Using screws longer than 5/8" will penetrate thru exposed top surface!




Step 2


Attach Ganging Hardware:
(when applicable)



When cabinets are to be ganged
together, attach Linking Hook &
Latch Hardware while cabinets
are flipped over.



Locking pin is used to keep latch
from hang down when not in use.



Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.