


# LOK

## HINGED MODESTY PANEL INSTALLATION

### Recommended tools



### Hardware enclosed



LAMINATE



ACRYLIC

**NOTE: all screws provided must be installed for proper installation and compliance with product warranty.**



LAMINATE



ACRYLIC

Lok tables are factory ready to receive a modesty panel. Laminate and frosted acrylic panels can be ordered to coordinate with the table length. **Magnetic hinges** automatically release when the table is tilted. Hinges are enclosed in the modesty panel carton located in a hardware bag with **HARDWARE ENCLOSED** sticker and taped to the modesty panel.

- With assistance from another person, lift and rotate table to set on the floor. (**NOTE:** support the hinged modesty panel while rotating the table to set on the floor to avoid damaging the hinge magnet)

### laminate modesty panel:

- Attach the hinges angle brackets to the back of the laminate modesty panel into pre-drilled holes with two #8 x 5/8" screws.
- Position the modesty panel with attached magnetic hinges to underside of table top and align with pre-drill holes in underside of top. Install two #8 x 5/8" screws per hinge.



### acrylic modesty panel:

- Attach the hinges angle brackets to the back of the acrylic modesty panel into holes in panel with machine bolts provided into the panel face trim covers.
- Position the modesty panel with attached magnetic hinges to underside of table top and align with pre-drill holes. Install two #8 x 5/8" screws per hinge.

