


# LOK

## FIXED MODESTY PANEL INSTALLATION


### Recommended tools



### Hardware enclosed



LAMINATE



ACRYLIC

**NOTE: all screws provided must be installed for proper installation and compliance with product warranty.**



LAMINATE



ACRYLIC

Lok tables are factory ready to receive a modesty panel. Laminate and frosted acrylic panels can be ordered to coordinate with the table length. **Fixed brackets** securely attach modesty panel to underside of table top. Brackets are enclosed in the modesty panel carton located in a hardware bag with **HARDWARE ENCLOSED** sticker and taped to the modesty panel.

### laminate modesty panel:

- Attach the leg of angle brackets without slot to the back of the laminate modesty panel into pre-drilled holes with two #8 x 5/8" screws.
- Position the modesty panel with attached bracket to underside of table top, attach with two #8 x 5/8" screws into pre-drilled holes.



### acrylic modesty panel:

- Attach the leg of angle brackets without slot to the back of the acrylic modesty panel into holes in panel with machine bolts provided into panel face trim covers.
- Position the modesty panel with attached bracket to underside of table top, attach with two #8 x 5/8" screws into pre-drilled holes.

