

Vision-T BASE SHROULD

Install Instructions

Recommended Tools



Hardware Included

- Bracket Part #47-VS0003A-BL (4) #8 x 5/8" Truss head Screws

Installation

Note:

1. Table upside down on a clean surface.
2. Slide the Shroud over the Adjustable Column (Figure A)
3. Attach Metal Foot to Adjustable Column. (See table frame assembly Instructions).
4. Attach Bracket to Shroud to secure Metal Foot (Figure B)
5. View with hidden lines shown (Figure C)

Figure A




Figure B





Figure C



Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.



225 CLAY STREET JASPER, INDIANA 47546



800.457.4511 TOLL FREE 812.482.3204 OFFICE



JSIFURNITURE.COM