



# FLUX

## Flux Locker Assembly

### Recommended tools



### Hardware enclosed

#8 1-1/4"  
FHP  
(QTY Varies)

#8 1-1/2"  
FHP  
(QTY Varies)



Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

### ATTACHING A TOP PANEL

Figure 1





Figure 2



1. Align the top panel so that the back of the panel is flush with the back of the locker(s). The panel should be centered horizontally
2. Screw the top panel to the locker(s) using #8 1-1/2" Screws

### ATTACHING A BACK/TOP PANEL

Figure 1



Figure 2



1. Center the top/back panel. The bottom of the back panel must be flush with the bottom of the locker(s)
2. Screw the back/top panel to the back and top of the locker(s) using #8 1-1/4" screws for the back and #8 1-1/2" screws for the top through the pre-drilled holes

# FLUX

## Flux Locker Assembly



Figure 1




Figure 2

### ATTACHING MULTIPLE LOCKERS

1. Align the two lockers so that they are flush on all sides
2. Screw the two lockers together using the holes found on the inside of the rightmost locker and the screws provided




Figure 3

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.