



Attaching Leg Base to Credenzas and Cabinets


Recommended Tools



Hardware Used

 #8 x 3/4" Pan Head Wood Screws

Leg Base Assembly on Credenzas & Pedestals



Step 1

Leg Base Installation


- Flip cabinet upside down and lay on flat clean and debris free pad.
- Turn leg base upside down and place on the bottom of the cabinet.
- Sides offset **A** should be equal on both side of the cabinet. Mark with a pencil the position of each hole on the mounting plates and tabs.

$$90'' \text{ A} = 9\frac{1}{16}''$$

$$72'' \text{ A} = 9\frac{1}{16}''$$


$$60'' \text{ A} = 9\frac{1}{16}''$$

- Fasten leg base to the bottom of the cabinet using #8 x 3/4" pan head screws



Step 2

- Carefully flip the cabinet upright and into place.
- Level cabinet front to back and side to side by rotating adjustable glides.



Notice To Installers: Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.