



FLUX OPEN PLAN

HOW TO ATTACH A TOP FRAME TO AN END SUPPORT STORAGE CREDENZA

Recommended Tools



Hardware Needed



5/16-18 x 2"
bolts

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

1. Align the holes in the bottom of the top from with the holes on the credenza (Figure 1)
2. Secure frame using 5/16-18 x 2" bolts. Bolts will go through the inserts in the top panel and into the threaded inserts in the frame

Figure 1





Figure 2



Lower view of Credenza