


FLUX OPEN PLAN

HOW TO ATTACH A MID SUPPORT BRACKET


Recommended Tools



Hardware Needed




1/4-20 x 2" PHP bolts



Hex Nuts with Washers

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Figure 1



1. Remove drawers to access spot holes
2. Using the spot holes on the inside of the cabinets, drill a 5/16" hole (Figure 1)
3. Position the bracket to align with the drilled holes in the side panel of the cabinet (Figure 2)
4. Secure with 1/4-20 x 2" bolts, hex nuts, and washers provided using the holes in the bracket and cabinets (Figure 3)




Figure 2

