


FLUX OPEN PLAN

HOW TO ASSEMBLE AN ADJUSTABLE HEIGHT END SUPPORT CREDENZA

Recommended Tools




Hardware Needed



#8 x 5/8 PHP Screws

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.

Figure 1



1. Position and secure bracket above the grommet so that it is centered from side to side and flush with the top edge (Figure 2)
2. Secure using $\frac{1}{4}$ -20 x $\frac{1}{2}$ " bolts and the threaded inserts (Figure 3)




Figure 2




Figure 3