


# FLUX OPEN PLAN

## HOW TO ATTACH AN END SUPPORT FRAME

### Recommended Tools




### Hardware Needed




1/4-20 x 1/2" PHP  
Machine Screws

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.


### Attaching to Stretchers



1. Align holes on end support frame with the holes on the metal stretcher(s) being attached (Figure 1)
2. Use the 1/4-20 x 1/2" machine screws provided to secure the stretcher(s) to the end frame. Hand tighten the screws until top is attached, then proceed to fully tighten. Repeat for all stretchers as necessary (Figure 2)



### Attaching to Aluminum Rail



1. Place aluminum rail on pre-attached L-Brackets so that it is flush on each end with the end supports (Figure 1)
2. Secure rail using 1/4-20 x 1/2" machine screws (Figure 2)

