

FLUX OPEN PLAN

INSTALLATION OF A PRIVACY SCREEN

Recommended Tools



5/32" Allen wrench



Figure 2




Figure 3




Figure 4




Figure 1

1. Remove both set screws located on the bottom of the aluminum rail using the 5/32" Allen wrench (Figure 1)
2. Slide privacy screen into the rail until it is centered (Figure 2 & 3)
3. Use the 5/32" Allen wrench to tighten the set screws against the privacy screen until it is secure (Figure 4)
4. Insert main extrusion cap on each end of the aluminum rail (Figure 5)




Figure 5

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.